

GoPro HD HERO2 Firmware Update

with CineForm Studio



STEP-BY-STEP INSTRUCTIONS:

- 1) Make sure your HD HERO2 camera is:
 - a. Turned OFF
 - b. Unplugged from computer
 - c. Loaded with an SD card
 - d. Battery is well charged
 - 2) Install CineForm Studio on your computer.
 - 3) Once successfully installed, close the CineForm Studio program.
 - 4) Insert SD card into your HD HERO2 camera.
 - 5) Turn ON your HD HERO2 camera.
 - 6) If your camera or SD card has not been used before, take a test photo or short video clip.
 - 7) Connect your HD HERO2 camera to your computer with USB cable.
 - 8) Open CineForm Studio software application.
 - 9) If an update is available, a dialog box will appear — click “Update”.
 - 10) CineForm Studio will automatically download and install the new firmware onto your HD HERO2 camera.
-

For questions, or issues during installation, please contact GoPro Support:

<http://gopro.com/support>